

## **INSTALLATION INSTRUCTIONS**

#64270... 5.0L, 302W, 1981 model & later only.Externally balanced engines (50 OZ. IN)Will suit internally balanced engine upon removal of the bolt-in counterweight, see note below.

## **IMPORTANT:** Before attempting installation please read these instructions fully.

**NOTE:** The PRO/RACER "All Steel" Crankshaft Vibration Damper has a precision machined inner bore which requires special attention prior to fitting. It is also important to note that your PRO/RACER Damper is supplied in factory "IN BALANCE" condition, therefore, if any balancing operations are carried out on the engine, weight must be added or removed from the crankshaft only.

## IMPORTANT: DO NOT drill any holes in your PRO/RACER Damper as this may void SFI -18.1 Certification

**NOTE:** For special purpose race engines with an **internally balanced crankshaft**, simply unscrew the two <sup>3</sup>/<sub>8</sub>" socket head cap screws and remove the counterweight.

- 1. Engine must be completely cold.
- 2. Remove water pump.
- 3. Remove original Damper carefully, using Damper Puller or Removal Tool.
- 4. It is necessary to check to ensure that the zero degree or TDC timing mark of your PRO/RACER Damper is in the same location when compared with your original Harmonic Damper (assuming your original Damper is in good condition). This can be determined by placing one Damper on top of the other and aligning the keyways. It is essential that both Dampers have the front, or pulley mounting face, pointing upwards. The 0° on the original Damper should line up with the 0° mark on the PRO/RACER Damper. Should the timing marks not correspond, check that the Inertia Ring has not slipped or rotated on the Hub. <u>Note:</u> You may have to purchase a Summit adjustable timing pointer.
- 5. Ford has used many different styles of Dampers with various pulley spacings, bolt hole and spigot combinations, therefore it is necessary to identify the Damper originally fitted to your engine by measuring with a steel rule through the bore of the Damper to establish the overall length, then refer to the respective instructions shown in the table below:

For Dimension: 3" refer (A) 3 3/16 " refer (B) 3 3/8" refer (C) 4" refer (D)

- (A) This Damper utilises an internal hollow bore to locate the crank pulley, no sleeve, circlip or spacers are required. Reinstall the pulley using the original bolts.
- (B) This Damper utilises an external raised boss to locate the crank pulley. Only the tubular sleeve is used with the circlip fitted in the circlip groove located at the stepped shoulder. Fit the sleeve into the Centre hub of the Damper and, with the circlip located between the Damper face and the crank pulley, fasten using the original bolts.
- (C) This Damper utilises the tubular sleeve with the circlip located in centre position circlip groove, together with 4 short spacers located between the Damper face and the crank pulley. Fasten with 4 new 1" long x 3/8" U.N.C. Hi-Tensile bolts (Min. grade 6) and tension to 32 lb/ft torque.
- (D) This Damper utilises the tubular sleeve with the circlip located in the outer groove together with both 4 short and 4 long spacers located between the Damper face and the crank pulley. Fasten with 4 new 11/2" long x 3/8" U.N.C. Hi-Tensile bolts (Min. grade 6) and tension to 32 lb/ft torque.

**NOTE:** -Most 1981 and late 5.0L engines generally have a 4" length, refer to (D).

-All the PRO/RACER Dampers are drilled to accept both 3- & 4-bolt hole pulleys.

-Use LOCTITE to secure the crankshaft and pulley bolts and spigot sleeve in Damper.

- 6. Inspect crankshaft snout and ensure there are no burrs or rust, if required polish with very fine emery paper or steel wool, wash clean.
- 7. Examine key, should the key be damaged or loose in the keyway groove of the crankshaft, install a new key.
- 8. Replace the front timing cover oil seal.
- 9. The PRO/RACER Damper can be installed using a Damper Installation Tool. However, you can make installation much easier by immersing the Damper in boiling water for 15 minutes or placing in a pre-heated oven at the lowest temperature (max. 250°F or 120°C) for 15 minutes. This process will expand the hub of the Damper.
- 10. If you are <u>NOT</u> using a workshop installation tool, it is **ESSENTIAL** that the Damper be pre-heated as outlined in step 9. above, to expand the hub. All subsequent steps will need to be followed carefully.
- 11. Smear crank snout and the timing case oil seal with clean oil.
- 12. If you are not using a Damper installation tool, remove Damper from boiling water (or oven), using insulated, heat proof gloves. Smear bore of Damper with oil.

## IMPORTANT DO NOT ALLOW DAMPER TO COOL

- 13. Immediately locate Damper on to the crankshaft and rotate until the hub engages in the key-way.
- 14. If using a Damper Installation Tool, install the Damper following the instructions supplied with your Damper installation tool and ignore step 15.
- 15. If you are not using an installation tool, quickly, utilizing a block of Aluminum to protect the machined face, drive the Damper onto the crankshaft. Rotate the Damper to ensure engagement in the keyway.
- 16. Promptly reinstall the Damper retaining bolt and washer and tension to 90 lb/ft torque.
- 17. Before reinstalling water pump, ensure there is a minimum of 1/8" clearance between Damper Inertia Ring and the water pump housing, check that the pulley alignment is correct.
- 18. <u>WARNING</u>: Some cast iron water pumps have a casting lug which must be ground off to clear the Damper Inertia Ring.
- 19. Re-check for adequate clearance of all components before re-starting engine.

Should you have any difficulty installing your PRO/RACER "All Steel" Damper, please contact:

USA:	PRO/RACE Tech-line	Tel: 734 740 0922	
Australia:	PRO/RACE Tech-line	Tel: +61 3 9584 3522	Fax: +61 3 9584 5194
Email:	tech@pro-race.com	Website: www.pro-race.com	

23 Oct 2018