

INSTALLATION INSTRUCTIONS

#64290 .. HOLDEN V8 253/308 incl. group A models

IMPORTANT: Before attempting installation please read these instructions fully.

NOTEt: The PRO/RACE "All Steel" Crankshaft Vibration Damper has a precision machined inner bore which requires special attention prior to installing

- 1. Engine must be completely cold
- 2. Remove original Damper carefully, using a Damper puller or removal tool
- 3. Inspect crankshaft snout to ensure there are no burrs or rust. If required polish with very fine emery paper or steel wool and wash clean
- 4. Examine key, should the key be damaged or loose in the key-way groove of the crankshaft, install a new key
- 5. Replace the front timing cover oil seal
- 6. The PRO/RACE Damper can be installed just like any other Damper using a Damper installation tool. However, you can make the installation much easier by immersing the Damper in boiling water for 15 minutes, or placing in a pre-heated oven at the lowest temperature (max 250°F or 120°C) for 15 minutes. This process will expand the hub of the Damper
- 7. If you are **NOT** using a professional installation toll, it is **ESSENTIAL** that the Damper be pre-heated as outlined in step 6 above to expand the hub. All subsequent steps will need to be followed carefully
- 8. Smear crank snout and the timing case oil seal with clean oil
- 9. If you are not using a Damper installation tool, remove Damper from boiling water (or oven) using insulated, heat proove gloves. Smear bore of Damper with oil
- 10. Immediately locate Damper on to the crankshaft and rotate until the hub located in the key-way

IMPORTANT - DO NOT ALLOW DAMPER TO COOL

- 11. If using a professional Damper installation tool, install the Damper follwing the instructions supplied with your installation tool and ignore step 12
- 12. If you are not using an installation tool, quickly, utilizing a block of aluminium to protect the machined face, drive the Damper on the crankshaft
- 13. Promptly reinstall the Damper retaining bolt and washer and tension to 100 lb/ft torque

NOTE: Use LOCTITE to secure the crankshaft and pulley bolts

Should you have any difficulty installing your PRO/RACER Damper, please contact:

PRO/RACE Performance Components

Email: tech@pro-race.com

Website: www.pro-race.com

OR alternatively please contact your place of purchase or closest distributor