



INSTALLATION INSTRUCTIONS

#34269.....Ford 289-351 V8, up to 1980 (ext. bal. 28.5 oz. in)

#34270.....Ford 5.0L V8, 1981 model & later only (ext. bal. 50 oz in)

Both models suit internally balanced engines upon removal of bolt-in counterweight, see note below.

IMPORTANT: **Before attempting installation, please read these instructions fully.**

NOTE: The PRO/SPORT SFI Bonded Steel Crankshaft Damper has a precision machined inner bore which requires special attention prior to fitting. It is also important to note that your PRO/SPORT Damper is supplied "IN BALANCE" condition, therefore, if any balancing operations are carried out on the engine, weight must be added or removed from the crankshaft only.

IMPORTANT: **DO NOT drill any holes in your PRO/SPORT Damper which may void your SFI-18.1 Certification**

For special purpose race engines with an **internally balanced crankshaft**, simply unscrew the two $\frac{3}{8}$ " socket head cap screws and remove the counterweight.

1. Engine must be completely cold.
2. Remove water pump.
3. Remove original Damper carefully, using Damper Puller or removal tool.
4. Ford has used three different TDC (Top Dead Center) locations in the SB V8 engine family and to accommodate all timing pointer locations, the PRO/SPORT Damper has been engraved with 3 sets of timing marks, only one will be used in timing operations. To determine which set of timing marks to use on your PRO/SPORT Damper you can either compare to the original Damper by aligning keyways and marking the appropriate set of timing marks on the PRO/SPORT Damper which correspond to the timing marks on the original Damper. Alternatively, on your engine, rotate the crankshaft until the key in the crank snout is pointing straight up in the 12 o'clock position. Temporarily align the PRO/SPORT Damper keyway with the key in the crank snout and observe which set of timing marks on the Damper lines up with your timing pointer.

NOTE: Once you have determined which timing marks suit your engine, you may want to highlight the degree mark for your initial timing setting (or full advance setting if you power time your engine) with paint, or white-out. White or yellow will show up best.

5. Inspect crank snout and ensure there are no burrs or rust. If required polish with very fine emery paper or steel wool, wash clean.
6. Examine key, should the key be damaged or loose in the keyway groove of the crankshaft, install a new key.
7. Replace the front timing cover oil seal.
8. The PRO/SPORT Damper can be installed using a Damper Installation Tool. However, you can make installation much easier by placing Damper in a pre-heated oven at the lowest temperature (max. 250°F or 120°C) for 15 minutes. This process will expand the hub of the Damper.
9. If you are **NOT** using a Damper Installation Tool, it is **ESSENTIAL** that the Damper be pre-heated as outlined in step 8 above, to expand the hub. All subsequent steps will need to be followed carefully.
10. Smear crank snout and the timing case oil seal with clean oil.
11. If you are not using a Damper Installation Tool, remove Damper from oven, using insulated, heat proof gloves. Smear bore of Damper with oil.

...turn over

12. Immediately locate Damper on to the crankshaft and rotate until the hub locates in the keyway.

IMPORTANT - DO NOT ALLOW DAMPER TO COOL

13. If using a Damper Installation Tool, install the Damper following the instructions supplied with your installation tool and ignore step 14.
14. If you are not using an installation tool, quickly, utilizing a block of Aluminum to protect the machined face, drive the Damper on the crankshaft.
15. Promptly reinstall the Damper retaining bolt and washer and tension to 90 lb/ft torque.
16. Ford has used many different styles of Dampers with various pulley spacings, bolt hole and spigot combinations, therefore it is necessary to identify the Damper originally fitted to your engine by measuring with a steel rule through the bore of the original Damper to establish the overall length, then refer to the respective instructions shown in the table below:

For dimension	3" refer (A)	3 ³ / ₁₆ " refer (B)
	3 ³ / ₈ " refer (C)	4" refer (D)

- (A) This Damper utilises an internal hollow boss to locate the crank pulley, no sleeve, circlip or spacers are required. Install pulley using the original bolts.
- (B) This Damper utilises an external raised boss to locate the crank pulley. Only the tubular sleeve is used with the circlip fitted in the circlip groove located at the stepped shoulder. Fit the sleeve into the centre hub of the Damper and, with the circlip located between the Damper face and the crank pulley, fasten using the original bolts.
- (C) This Damper utilises a tubular sleeve with a circlip at the center position circlip groove, together with 4 short spacers located between the Damper face and the crank pulley. Fasten with 4 new 1" long x ³/₈" U.N.C. Hi-Tensile bolts (Min. grade 6) and tension to 32 lb/ft torque.
- (D) This Damper utilises a tubular sleeve with the circlip located in the outer location utilising both 4 short and 4 long spacers located between the Damper face and the crank pulley. Fasten with 4 new 1 ¹/₂" long x ³/₈" U.N.C. Hi-Tensile bolts (Min. grade 6) and tension to 32 lb/ft torque.

NOTE: Use LOCTITE to secure the crankshaft and pulley bolts and spigot sleeve in Damper.

17. Before reinstalling water pump, ensure there is a minimum of ¹/₈" clearance between Damper ring and the water pump housing, check that the pulley alignment is correct. **WARNING:** Some cast iron water pumps have a casting lug which must be ground off to clear Damper Ring.
18. Re-check for adequate clearance of all components before re-starting engine.

Should you have any difficulty fitting your PRO/SPORT Damper, please contact:

USA:	PRO/RACE Performance Products, Tech-line	Tel: 734 740 0922
Australia:	PRO/RACE Performance Products, Tech-line	Tel: +61 3 9584 3522 Fax: +61 3 9584 5194
Email:	tech@pro-race.com	Website: www.pro-race.com

24Oct2018